



- NOTES:
- 1- ATTACH RECEPTACLE TO RECEPTACLE BOX THEN ATTACH TO FRONT COVER USING SCREWS PROVIDED.
 - 2- ATTACH FRONT COVER TO BASE (803632) USING 4- 85589 PAN HEAD SCREWS.
 - 3- PUT 4- 85132 HEX HEAD SCREWS INTO BAG AND SEAL.
 - 4- PLACE BASE ASSEMBLY, BAG CONTAINING SCREWS AND, 2- 803631 EXTENSIONS INTO BOX FOR SHIPPING.

ITEM NO.	PART NUMBER	QTY.
1	85589	4
2	85132	4
3	803631	2
4	803632	1
5	803639	1
6	803743	1
7	RECEPTACLE	1
8	85646	4
9	803562	8
10	803838 277V	1



TITLE:
4" H SUB BASE ASSEMBLY

SIZE	DWG. NO.	REV
G	803744	01
SCALE: 1:8	WEIGHT:	SHEET 1 OF 1

			NAME	DATE
			DRAWN WWebber	25 Sep 2014
			CHECKED	
			ENG APPR	
			MFG APPR	
			Q.A.	
01	25Nov15	REVISED PART #803632	WW	
REV	DATE	NOTES	BY	
APPLICATION			DC	NOT SCALE DRAWING

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.