



**NOTES:**

- 1- ATTACH RECEPTACLE TO RECEPTACLE BOX THEN ATTACH TO FRONT COVER USING SCREWS PROVIDED.
- 2- ATTACH FRONT COVER TO BASE (803641) USING 4- 85589 PAN HEAD SCREWS.
- 3- PUT 4- 85132 HEX HEAD SCREWS INTO BAG AND SEAL.
- 4- PLACE BASE ASSEMBLY BAG CONTAINING SCREWS AND 2- 803631 EXTENSIONS INTO BOX FOR SHIPPING.

ITEM NO.	PART NUMBER	QTY.
1	85589	6
2	85132	4
3	RECEPTACLE	1
4	803641	1
5	803640	2
6	803745	1
7	803639	1
8	803562	8
9	85646	4

REV	DATE	NOTES	BY	FINISH	COMMENTS:
APPLICATION			DC NOT SCALE DRAWING		

TITLE:

## 6" H SUB BASE ASSEMBLY

SIZE	DWG. NO.	REV
G	803746	00
SCALE: 1:8	WEIGHT:	SHEET 1 OF 1

**PROPRIETARY AND CONFIDENTIAL**

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.