


- NOTES:
 1- ATTACH RECEPTACLE TO RECEPTACLE BOX THEN ATTACH TO FRONT COVER USING SCREWS PROVIDED.
 2- ATTACH FRONT COVER TO BASE (803641) USING 4- 85589 PAN HEAD SCREWS.
 3- PUT 4- 85132 HEX HEAD SCREWS INTO BAG AND SEAL.
 4- PLACE BASE ASSEMBLY BAG CONTAINING SCREWS AND 2- 803631 EXTENSIONS INTO BOX FOR SHIPPING.

ITEM NO.	PART NUMBER	QTY.
1	85589	6
2	85132	4
3	RECEPTACLE	1
4	803641	1
5	803640	2
6	803745	1
7	803639	1
8	803562	8
9	85646	4

		NAME		DATE	
		DRAWN	WWebber	25 Sep 2014	
		CHECKED			
		ENG APPR			
		MFG APPR			
		Q.A.			
		MATERIAL	COMMENTS:		
		FINISH			
REV	DATE	NOTES	BY		
APPLICATION			DC	NOT SCALE DRAWING	

TITLE:
6" H SUB BASE ASSEMBLY 

SIZE	DWG. NO.	REV
G	803746	00
SCALE: 1:8	WEIGHT:	SHEET 1 OF 1

PROPRIETARY AND CONFIDENTIAL
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.