



- NOTES:  
 1- ATTACH RECEPTACLE TO RECEPTACLE BOX THEN ATTACH TO FRONT COVER USING SCREWS PROVIDED.  
 2- ATTACH FRONT COVER TO BASE (803641) USING 4- 85589 PAN HEAD SCREWS.  
 3- PUT 4- 85132 HEX HEAD SCREWS INTO BAG AND SEAL.  
 4- PLACE BASE ASSEMBLY BAG CONTAINING SCREWS AND 2- 803631 EXTENSIONS INTO BOX FOR SHIPPING.

ITEM NO.	PART NUMBER	QTY.
1	85589	6
2	85132	4
3	RECEPTACLE	1
4	803641	1
5	803640	2
6	803745	1
7	803639	1
8	803641	8
9	85646	4

REV	DATE	NOTES	BY	NAME	DATE
				DRAWN WWebber	25 Sep 2014
				CHECKED	
				ENG APPR	
				MFG APPR	
				Q.A.	
				MATERIAL	COMMENTS:
				FINISH	
				APPLICATION	DC NOT SCALE DRAWING

TITLE:  
**6" H SUB BASE ASSEMBLY**

**Applied Comfort**

SIZE	DWG. NO.	REV
<b>G</b>	<b>803746</b>	<b>00</b>
SCALE: 1:8	WEIGHT:	SHEET 1 OF 1

**PROPRIETARY AND CONFIDENTIAL**  
 THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.