



- NOTES:
- 1- ATTACH RECEPTACLE TO RECEPTACLE BOX THEN ATTACH TO FRONT COVER USING SCREWS PROVIDED.
 - 2- ATTACH FRONT COVER TO BASE (804435) USING 4- 85589 PAN HEAD SCREWS.
 - 3- PUT 4- 85132 HEX HEAD SCREWS INTO BAG AND SEAL.
 - 4- PLACE BASE ASSEMBLY BAG CONTAINING SCREWS AND 2- 804437 EXTENSIONS INTO BOX FOR SHIPPING.

ITEM NO.	PART NUMBER	QTY.
1	85589	6
2	85132	4
3	804666	1
4	804435	1
5	804437	2
6	RECEPTACLE	1
7	803639	1
8	85646	4
9	803562	8

TITLE:		
8" H SUB BASE ASSEMBLY		Applied Comfort
SIZE	DWG. NO.	REV
G	804667	00
SCALE: 1:8	WEIGHT:	SHEET 1 OF 1

						NAME		DATE
						DRAWN	WWebber	22 Aug 2017
						CHECKED		
						ENG APPR		
						MFG APPR		
PROPRIETARY AND CONFIDENTIAL						Q.A.		
						MATERIAL		COMMENTS:
						FINISH		
	REV	DATE	NOTES	BY				
	APPLICATION				DO NOT SCALE DRAWING			
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <INSERT COMPANY NAME HERE>. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <INSERT COMPANY NAME HERE> IS PROHIBITED.								