

INSTALLATION INSTRUCTIONS
PLACE EXTENSION AGAINST FRONT OF SLEEVE
ENSURE TOP AND SIDES ARE FLUSH
ATTACH TO SLEEVE USING SELF TAPPING SCREWS PROVIDED
IN 7 PLACES THREE IN THE TOP FLANGE AND TWO ON EACH SIDE

NOTE:

WHEN INSTALLING THE UNIT PROVISIONS MUST BE MADE TO EXTEND THE OUTSIDE FRESH AIR AND CONDENSING AIR EXHAUST DIVIDERS TO REACH THE EXTERIOR LOUVER. IF THIS IS NOT DONE THE AIR WILL RECIRCULATE AND THE UNIT WILL NOT RUN PROPERLY AND MAY FAIL PREMATURELY.

SLEEVE EXTENSION ADDS 2 3/8" DEPTH TO THE <u>INSIDE</u> OF A 16x42" SLEEVE





						NAME		DATE		
					DRAWN	WWebber	er		24 Jul 2015	
					CHECKED					TIT
					ENG APPR					
					MFG APPR					
			+		Q.A.					
PROPRIETARY AND CONFIDENTIAL THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF <insert company="" here="" name="">. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF <insert company="" here="" name=""> IS PROHIBITED.</insert></insert>					MATERIAL		COMMENTS:			SIZ
	REV	DATE	NOTES	BY	FINISH					
	,		APPLICATION	DC	DO NOT SCALE DRA					SC
			1					l		

SLEEVE EXTENSION
INSTRUCTIONS

Applied Comfort

SIZE DWG. NO. REV 00 SCALE: 1:10 WEIGHT: SHEET 1 OF 1

3 2