

PREPARING SLEEVE TO ACCEPT 16 SERIES UNITS




STEP ONE: SLIDE WALL SLEEVE CHASSIS SUPPORTS INTO SLEEVE SLOTTED END TO FRONT

STEP TWO: TAKE WALL SLEEVE BOTTOM SEAL AND PLACE IT INTO SLEEVE ALIGNING FRONT FLANGE (FLANGE WITH HOLES) WITH BACK OF ROOM AIR OPENING. THE BACK FLANGE OF THE BOTTOM SEAL WILL SLIDE INTO THE SLOTS CUT OUT OF THE CHASSIS SUPPORTS.

STEP THREE: USING THE BOTTOM SEAL HOLES AS A GUIDE DRILL 2 - 1/8" HOLES TO SECURE THE BOTTOM SEAL TO THE SLEEVE.


STEP FOUR: REMOVE BOTTOM SEAL AND APPLY A GENEROUS BEAD OF CALKING TO THE BOTTOM SIDE OF THE FRONT FLANGE. PLACE THE BOTTOM SEAL BACK INTO POSITION AND SECURE WITH TWO SCREWS PROVIDED.

THE ROOM SLEEVE IS NOW READY TO ACCEPT THE MODIFIED 16 SERIES UNIT.



ALIGN FRONT EDGES
CALK UNDERSIDE OF BOTTOM SEAL
TO ENSURE NO WATER PENETRATION
INTO ROOM SIDE

CHASSIS SUPPORT SHOULD
REACH BACK OF SLEEVE



DETAIL B
SCALE 1 : 2

					NAME		DATE
					DRAWN	WWebber	13 Jun 2013
					CHECKED		
					ENG APPR		
					MFG APPR		
					Q.A.		
					MATERIAL		COMMENTS:
REV	DATE	NOTES	BY	FINISH			
APPLICATION				DO NOT SCALE DRAWING			

Applied Comfort

TITLE: **WALL SLEEVE
MODIFICATION
DRAWING**

SIZE G	DWG. NO. 803198	REV 00
SCALE: 1:10	WEIGHT:	SHEET 1 OF 1

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS
DRAWING IS THE SOLE PROPERTY OF
<INSERT COMPANY NAME HERE>. ANY
REPRODUCTION IN PART OR AS A WHOLE
WITHOUT THE WRITTEN PERMISSION OF
<INSERT COMPANY NAME HERE> IS
PROHIBITED.